Sbach 1.2m

Kit contains:
*Fuselage
*Cannopy
*Backbone
*Elevator
*Rudder
*SFG's

*Wings
*Landing gear
*Wheell pants
*Anti-torsion reinforcements(2x)
*Bag with hardware

*Carbon rods and strips:
 - 2x 1x3x1000 - fuselage
 - 2x 1x5x1000 - wing
 1x tube 2/1x500 - elevator pushrod
 - 1x 1x5x245mm - elevator
 - 1x 1x3x245mm - elevator

Bag with hardware includes:

4x screw M1,6x4 ... ball links
2x screw M2x5 ... rudder hinge
2x screw M2x5 ... pull pull cable tightener
1x screw M2x8 ... tail wheel shaft
2x nut M2 ... tail wheel shaft
2x socked head M3x15 ... landing gear shaft
4x washer 3 ... landing gear
2x nut M3 ... landing gear
2x nut M3 ... landing gear
2x screw 2,9x6mm ... lading gear plate
4x screw 2,9x9mm ... X motor mount
4x socket head bolt M3x6 ... X motor mount

2x "Z" bend ... elevator pushrod
1x firewall
1x control horn set
2x wheel pant mounting tab
1x LG plate
2x LG stirrup
4x ball link
2x wheel 50mm
1x wheel 25mm
1x plastic tube 3/2x15mm - pushrod support
2x carbon strip 1x3x100mm - elevator reinf.
2x carbon rod 1.8x50mm - aileron pushrod
1,5m kevlar cable - rudder pull pull

Control horn set:

1. Rudder hinge - fuselage (2ks)
2. Bottom rudder hinge
3. Elevator servo arm extension
4. Aileron control horn (2ks)
5. Rudder control horn
6. Rudder servo arm extension
7. Tail wheel
8. Elevator control horn

You will need:

* hex key nr.2
* phillips screwdriver
* screwdriver
* CA glue with kicker
* sharp knife
* flat file
* sand paper 100-500
* driller 3mm
* about 5 hours of your time

A

carbon 3x1x1000 mm

B

CA CA CA CA

C

bottom side of wing facing up!

elevator cutout down!

D

1

2.

CA

3.

CA

carbon 1x5x1000 mm

E

carbon
1x3x100 mm

carbon
1x3x245 mm
1x5x245mm

CA

CA

CA

F

CA

H

L+R

CA

CA

G

CA

I

3mm

socked head M3x15mm

washer 3mm

nut M3

wood screw 2.9x6mm

CA

CA

CA

J

CA

CA

CA

CA

CA

L

CA CA

K

M

CA

CA

M2x5

M2x8

CA

CA

M2x5

N

cca 25mm

CA

CA

O

110mm

CA

M2x5

CA